

# Sleek

## Fine fabric wash

For wool and Silk garments



Sleek Is a low suds clear neutral biodegradable surfactant for fabric wash of delicate and natural protein fabrics like silk and wool. pH balanced, is extremely safe to skin. It can be used for machine washing in the gentle cycle, or for hand washing. Contains dye transfer inhibitors to prevent migration and bleeding of colours. Sleek is formulated with glycols that makes protein fibres (Silk and wool) softer and durable.

- Ideal for manual or machine wash
- Biodegradable and non toxic
- Neutral and safe to skin
- Concentrated product
- Contains glycols to impart extra softness
- Does not contain harmful bleach or phosphates

**Specifications :**

Appearance : Viscous liquid  
 pH : 6.5 to 7.0  
 Surfactant : Anionic and Non ionic  
 Temperature : Works in cold or warm water



**Dosage**

Type of wash & Fabric load	Mild	Normal	Stubborn	Extreme Stubborn
Machine (TL &FL)	5ml per Kg	6ml per Kg	8ml per Kg	10ml per Kg
Hand Wash	5ml per Kg	6ml per Kg+	8ml per Kg	10ml per Kg

## **Directions for use:**

### **Machine wash**

Silk and wool are universally accepted as a luxury fibers. Before you put a silk or wool item in the machine, check the tag to see if it can be machine washed. Some clothes are not recommended for machine wash.

Load the machine and add sleek detergent .Follow the dosing instructions on the pack.

Switch your machine to delicate wash option and operate on minimum spin.

Do not rinse dry. Gently squeeze over the basin to remove excess water

Don't dry in direct sunlight.

### **Hand Wash :**

The safest way to wash delicate silk and woolen garments at home is to hand wash them. If the fabric care label tells you to "Dry Clean" or not machine wash, then it's best to wash by hand.

Follow the step-by-step instructions to hand wash silk and wool.

1.Fill the basin with luke warm or cold water

2.Add the amount of Sleek detergent suggested on the label, or just enough to create suds that cover the surface of the water.

3. Submerge the garment . Leave the item to soak for three minutes.

4. Use your hands and plunge the garment up and down in the water gently to remove any dirt. Swish it about and gently squeeze the suds through the fabric. Rinse the item under fresh water till the water runs clear and all the soap has been washed off.

5. When washing silk use a towel to soak up the moisture from the silk garment, but don't rub or agitate the item. For woolen clothes gently squeeze over the basin to remove excess water .

6. Place the item on a hanger or a drying rack. Leave out of direct sunlight for drying.

### **Safety Precautions:**

Keep container well closed.

Keep out of reach of children's reach and sight.

Never mix SLEEK with ammonia, ammonia-based products or acidic products.

### **First Aid Measures :**

If spilled on your body do not try to wipe dry. Wash with plenty of water.

In case of eye contact keep eye lids open and flush well with water. If irritation persists get medical help.

If ingested drink water to dilute. Take emergency medical care.

If allergic to detergents avoid manual wash. Wear gloves and eye protectors during machine wash and ensure no spillage on clothes.

### **Useful Tips for washing Silk and Wool :**

Don't wash silk and woolen fabrics along with heavy pieces of clothing like jeans.

To test silk quality, crush the fabric in your hand, then let go. If it feels full and "liquid" and smooth's out quickly, it probably can be hand-washed. If it holds the wrinkles, have the garment dry-cleaned.

Before washing colored silk, test for color fastness. Dampen the fabric inside a seam and wait a few minutes. Then wipe the spot with a white cloth. If the color comes off, the dye will bleed when washed, and you must only dry-clean the garment.

Do not use hot water to wash silk and wool. Being natural fibres , once silk and wool shrinks, the damage is irreversible. Do not spray or wet silk and wool when ironing.

Keep silk and wool out of the sun for drying.

### **Storage :**

Keep out of reach of children.

Screw on cap tightly after use.

Store in a cool and dry area away from direct sunlight .

**Packaging :** 500ml / 1000ml / 5 Ltr and 25 Ltr Jerry cans

**Shelf life:** Two years from the date of manufacture

**Important :**

Be sure to read all Directions, Safety and First Aid Measures on product labels before use of SLEEK or any INCON product. If in doubt, get in touch with INCON customer service. Material Safety Data Sheets for all INCON products are available by visiting [www.inconproducts.in](http://www.inconproducts.in)

**Non Warranty :**

Manufacturer or seller of this product makes no warranty expressed or implied concerning the use of this product other than the aforementioned purpose. Manufacturer or seller is not liable for any injury or damage caused by this product arising out of misuse, misunderstanding or any application not specifically described and recommended on this data sheet.

**Guarantee :**

INCON's production and quality control ensures uniform quality. However if you are dissatisfied with the performance of the product, you may return any unused portion for credit or replacement within 12 months of the date of manufacture.



Keep out of  
reach of  
Children



IRRITANT

**INCON Products**

Kormala, Chalakudy, Thrissur Dist.,  
Kerala State, S. India, Pin. 680724

[www.incon.net.in](http://www.incon.net.in)

Email: [products@incon.net.in](mailto:products@incon.net.in)

Consumer Care No: +91 8113800999

Lic. No: TIO/Mom/196/16-17/MSME

